

INSTALLATION INFORMATION

Recommendations on laying the special leather floor “Plancher” For shell buildings:
even out the floor with cement to make it as level as possible (in accordance with the VOB norm).

In existing buildings:

The existing floor must be made as even as possible by smoothing it/balancing it out (in accordance with the VOB norm).

Installation:

The surface of the special leather floor tiles must be fully covered with hybrid adhesive* and laid out tile by tile. Please ensure a narrow gap for as good an alignment as possible and to guarantee e.g. that liquids cannot permeate the joints. Laying the tiles down roughly in advance and during installation will help you to see how to lay the pattern without creating gaps or misalignments in the pattern.

The tiles can be cut to size in situ using a hand-held circular saw.

To ensure good adhesion of the tiles at the joints and in the central area, weights should be placed on them for a min. of 1 hour.

A 1cm quarter round, foot edge or metal edge is recommended to finish the tiles at the wall. Adhesive recommendation: “P 685 SICURE Elast Universal” one-component and low-emission product by Thomsit