

CARE TIPS AND REPAIRS

CARE TIPS and REPAIRS “Plancher” should be regularly mopped using a damp, not wet, mop, lukewarm water and neutral cleaners.

If there are more stubborn stains to remove (e.g. shoe marks), these can be cleaned intensively by hand using the non-abrasive side of a sponge.

Liquids such as red wine and cooking fat should be removed. Provided they are removed quickly (not left to dry or soak through), the liquids/substances will not leave any marks.

If you want to give the surface a special clean, we recommend using a care and cleaning product by the company “RZ” developed especially for elastic floors.

If the surface is damaged by e.g. sharp-edged objects, you can carry out a “fill-up” repair (evening out small bumps) or “Airbrush” repair (repairing the colour).